

DOMED CHROME SHOWER TRAY WASTE 35MM INSTALLATION AND ASSEMBLY INSTRUCTION

STANDARD SHOWER WASTE FITTING AND ASSEMBLY INSTRUCTION

1. Remove upper assembly and seals from the bottle trap
2. Reassemble on shower tray as shown on diagram.

NB: The upper seal is optional to fit and if preferred. because of aesthetic, can be left out.

3. To clean trap, remove dome then twist and remove internal section (not shown). Wipe clean and refit complete.

NB: The domed cap does not have to be fitted. A suitable quality silicone sealant should be used on all surfaces against the shower tray.

