

## Fitting & Care Instructions - Bath Combined Waste & Overflow 1 1/2"

Illustration refers to a poly plug version, though this instruction also applies to chrome plug version.

1. Assemble components as shown on line drawing.
2. A light application of silicone sealant is recommended between the waste grid and the bath to ensure a watertight seal.
3. Care should be taken not to over tighten the centre screw.
4. Once fitting has been completed carefully clean all plated surfaces. The finished surface on this product are hard and durable and should be cleaned with warm soapy water and then wiped with a dry cloth. Under no circumstances should any aggressive or abrasive cleaning agent be used as this could lead to a deterioration in the high quality finish.

