


Quad Shower Enclosure Installation Instructions



□ 800x800x1900MM

- Please read these instructions in full before installing


IMPORTANT

- Check that the tray has been installed to the manufacturer's instructions, is level, has been tiled onto and sealed.
Please note - All product is supplied without a tray.
- Opening wall adjustments
800mm Quad - adjustment = 780 - 800mm
























GENERAL SAFETY INSTRUCTIONS

- Do not fix the wall profile to newly plastered, painted or papered walls as chemical reaction may cause discolouration to the surface finish.
- Important: The wall plugs included in this pack are for solid walls only. If the product is to be mounted on a partition or stud wall, specialised fixings should be purchased separately.
- Fixing tips; A piece of insulating tape or a couple of layers of masking tape applied to the wall before marking out the fixing holes will help stop the drill from wandering, particularly on tiled surfaces.
- When working near a basin or bath insert the plug into the waste, this will help you avoid losing small parts. Also take care not to drop accessories or tools onto the bath or basin, use a towel or bathmat to protect delicate surfaces.
- CAUTION!
Before drilling into any walls check that there are no hidden cables or pipes. Exercise great care when using power tools near water. The use of a residual current device (RCD) or cordless drill is recommended. Always double check the positioning and measurements before drilling holes.
- This product is heavy and requires two people during lifting and operations.
- Glass is delicate, support on cardboard to minimise risk of damage.











IDENTIFICATION OF PARTS




Fixings & fittings supplied

Item No.:	Part	Quantity	Item No.:	Part	Quantity
1		x2	10		x4
2		x2	11a		x1
3		x2	11b		x1
4		x2	12a		x2
5		x6	12b		x2
6	 ST4x12	x14	15		x2
7	 ST4x45	x6	16		x2
7a	 ST4x30	x8	17		x2
8		x6	18		x2
9a		x2	20a		x4
9b		x2	20b		x4
9c		x2			

Tools required (not supplied)


Drill		Pencil	
Ø3 Metal drill bit		Silicone sealant gun	
Ø6 Masonry drill bit		Silicone sealant	 Silicone sealant
Cross-Head screwdriver		Spirit level	
Tape Measure		Rubber mallet	

① ASSEMBLY INSTRUCTIONS




Left hand side panel

- Clip head profile cover cap (12a) onto head profile (4).
- Assemble head profile (4) with side panel (2) using two screws (7a).
- Clip cill profile cover cap (12b) onto cill profile (4).
- Assemble cill profile (4) with side panel (2) using two screws (7a).




② ASSEMBLY INSTRUCTIONS




Right hand side panel

- Clip head profile cover cap(12b) onto head profile (4).
- Assemble head profile (4) with side panel (2) using two screws (7a).
- Clip cill profile cover cap(12a) onto cill profile (4).
- Assemble cill profile (4) with side panel (2) using two screws (7a).



③ ASSEMBLY INSTRUCTIONS



Ø3 Meta drill bit

10



x4


6




ST4x12

x8


- Using a pencil, mark the positions of the glass retaining brackets (10) on the head and cill profiles (4).
- Use a 3mm drill bit suitable for metal to create pilot holes.
- Use two screws (6) per bracket to attach the glass retaining brackets to the head and cill profiles (4).



④ ASSEMBLY INSTRUCTIONS




- Slide wall channels (3) onto frame.
- Position assembly using spirit level and tape measure to ensure alignment.
- Mark positioning using a pencil.




⑤ ASSEMBLY INSTRUCTIONS




Ø6 Masonry drill bit





- Using a pencil, mark the positions of the pre-drilled fixing holes on the wall channel (3).
- Drill the marked holes using a 6mm masonry drill bit.
- Install supplied wall plugs (8). Note: Only where suitable for wall type.
- Using screws (7), fix wall profiles (3).




3




3



Ø6mm





8



7

⑥ ASSEMBLY INSTRUCTIONS

- There is 20mm of adjustment on each profile (3), allowing for the square positioning of the frame.



⑦ ASSEMBLY INSTRUCTIONS



Ø3 Metal drill bit

5



x6





6




ST4x12

x6


- Once positioned, prepare the frame using a 3mm metal drill bit.
- Use screws (6) and caps (5) to fix the frame to the wall channels (3).



⑧ ASSEMBLY INSTRUCTIONS




- Fix upper (20a) and lower (20b) rollers to the sliding doors (1). Each roller features a mounting screw and cover cap.




⑨ ASSEMBLY INSTRUCTIONS






- Mount the sliding doors by hanging from the upper roller first.
- Once the upper roller is correctly seated in the head profile, the lower roller can be clipped into the cill profile by pressing downwards on the roller body.
- Ensure both rollers are correctly seated before proceeding.



10 ASSEMBLY INSTRUCTIONS



- With the careful aid of a rubber mallet, install seals (16) to the closing face of each sliding door.
- Again using a rubber mallet, install seals (17) to the outside edge of the fixed panels.
- Finally and again using the rubber mallet, install seals (18) to the outside edge of each sliding door.
- During the installation phase, take careful note of the orientation of each seal.



11 ASSEMBLY INSTRUCTIONS

9a

9b

9c


- Secure handle using components (9a, 9b and 9c).




x2

x2


x2



12 ASSEMBLY INSTRUCTIONS



- The sliding doors should now be adjusted to ensure that they meet squarely when in the closed position.
- This can be done by turning the screw on the bottom of the top roller.
- A clockwise turn will raise the roller whilst an anticlockwise turn will lower the roller.



13 ASSEMBLY INSTRUCTIONS

15



x2

11a




x1

11b




x1


- Clip into place the profile cover caps (11a, 11b and 15) on the top of each wall profile (3).



14 ASSEMBLY INSTRUCTIONS



- Apply silicone sealant to the outside of the enclosure.
Please note: Do not apply silicone sealant to the inside of the enclosure.



CLEANING-general

Use only warm soapy water and damp cloth/sponge on a regular basis.
Do not use abrasive scouring powders, chemicals or aerosol cleaners-these may result in damage to the surfaces, in particular, the plated component parts.

Sealant drying times may vary in cold damp conditions and will be extended where thicker beads of sealant are applied. Allow sealant to dry completely before exposing to water.

We have taken great care to ensure that this product reaches you in perfect condition. However should any parts be damaged or missing please contact your point of purchase. This does not affect your statutory rights. In addition if you require replacement parts your point of purchase will be happy to assist.